

THE TEMPERATURE SENSOR SHOWS AN IRRELEVANT VALUE (-252°C)

The temperature sensor shows -252°C or another irrational value.

The sensor is not connected or broken. Measure the sensor (resistance at 20°C, 1090Ω, 4.5Ω/K, higher resistance with higher temperature).