

STD-03 VALVE AND ACTUATOR WATER HEATING

Together with STD-01 eller STD-02 this code specifies the valve and actuator to be used.

The code should be entered in the following format:

For example: **STD-03-2V-15-0040**

STD-03 tells you it is a code for water heating.

-2V tells you it is a 2-way valve (can also be 3V for 3-way valve).

-15 tells you the pipe diameter (in this case DN 15).

-0040 is the KVS-value (0,4) for the valve actuator.