

## STC-03 EXTRACT AIR DAMPER

Extract air damper is open when exhaust fan is running. Can be used to protect the unit in case of fire.