

STB-08 PRESSURE CONTROL EF, AIR FLOW CONTROL SF AND AIR FLOW MONITORING EF

The supply air fan speed is controlled to maintain a constant airflow, while the extract air fan aims to maintain a constant duct pressure.

It is possible to set three different setpoints per fan, and the amount of air passing through each fan can be read on the handheld terminal.