

STB-06 AIR FLOW CONTROL SF/EF

The fan speed is controlled to maintain a constant airflow.

It is possible to set three different airflow setpoints per fan, and the amount of air passing through each fan can be read on the handheld terminal.

Variable speed control fans are controlled to maintain the air flow setpoint for example when filter is dirty.