

STB-05 PRESSURE CONTROL EF, SF SLAVE, AIR FLOW MONITORING

The extract air fan speed is controlled to maintain a constant duct pressure, and the supply air fan is controlled to match the same airflow as the extract air fan.

The airflow through the fans is measured and displayed on the handheld terminal.