

STE-10 NIGHT COOLING WITH OUTDOOR AIR

Climatix is set up to use cool outdoor air to cool the building during summer nights.

- If the outdoor temperature has stayed above 12 °C during the day, the unit starts at night to check the exhaust air temperature inside the building.
- If the exhaust air temperature is higher than the setpoint, the unit continues cooling using outdoor air.
- If night cooling is combined with a room temperature sensor, the room temperature is measured continuously. In this case, the unit only starts night cooling when the room temperature is above the setpoint.