

STD-13-2 REVERSIBLE COOLING/HEATPUMP CONTROL WITH PRE-HEATER

Climatix is configured to control a reversible cooling/heatpump as follows:

- **A potential free digital output** to determine cooling or heating mode. Closed during heating.
- **0-10V analog output.** 10V indicates full heating or cooling while 0V indicates neither heating nor cooling.
- **Aux alarm** from the cooling/heatpump.

Besides providing sufficient temperature to the cooling/heatpump the heating coil works as extra heating if the cooling/heatpump can maintain the temperature setpoint.