

## STH-D1R- SMOKE DETECTORS

The unit can be fitted with smoke detectors, placed in supply and/or extract air duct. If the detector indicates smoke an alarm is triggered in Climatix.

STH-D1R-00	<p>Control unit for smoke detectors. <a href="#">ABAV-S3</a></p> <p>Up to thirty smoke detectors, either ionizing or optical, can be serially connected. Upon alarm from any of the detectors, in this case Fire alarm 1 is triggered in Climatix.</p> <p>A 2.2 kΩ termination resistor is connected to the last detector in the series to ensure proper monitoring of the circuit.</p>
STH-D1R-10	<p>Smoke detector in supply air. Smoke detection triggers an alarm in control unit. (STH-D1R-00) <a href="#">UG8-O</a></p>
STH-D1R-11	<p>Smoke detector with built-in control unit in supply air. <a href="#">UG8-E-24</a></p> <p>Smoke detection triggers Fire alarm 1 in Climatix.</p>
STH-D1R-12	<p>Smoke detector with built-in control unit in supply air (DiBt approved) <a href="#">UG-5-AFR-230V-Z</a></p> <p>Smoke detection triggers Fire alarm 1 in Climatix.</p>
STH-D1R-20	<p>Smoke detector in extract air. Smoke detection triggers an alarm in control unit (STH-D1R-00) <a href="#">UG8-O</a></p>
STH-D1R-21	<p>Smoke detector with built-in control unit in extract air. <a href="#">UG8-E-24</a></p> <p>Smoke detection triggers Fire alarm 1 in Climatix.</p>
STH-D1R-22	<p>Smoke detector with built-in control unit in extract air (DiBt approved) <a href="#">UG-5-AFR-230V-Z</a></p> <p>Smoke detection triggers Fire alarm 1 in Climatix.</p>